



FEATHER TOUCH MPFI SWITCH

WIRING DIAGRAM

REAR VIEW



FRONT VIEW



RPM Setting For MPFI Micro Switch

1. Turn On Ignition and Set Switch in Petrol Mode
2. Turn Off Ignition.
3. Keep Switch continue pressed and start the car
4. Level Indicator LEDs will glow
5. Release Switch Start Car.
6. Level indicator LEDs will start blinking
7. Now press Accelerator Stable to 2000 RPM
and press switch one time
8. Level LED now stop blinking
9. Setting is completed now.
10. Turn Off the car
11. Turn On Ignition and Set Switch in Gas Mode
12. Check for switching over is ok or not.